


# EZ-ZIP Round Trade Show Archway

## Assembly Instructions

1. 4pc Shock-Cord Poles (4)
2. Top Poles (x2)
3. Support Poles (x3)
4. Corner (x4)
5. Graphic
6. Hex Wrench
7. Hex Screws (x6)
8. Bottom Poles (x2)


### 1 Parts Removing

Remove all parts from the carrying case and lay them out on a clean flat surface. Make sure you have all the components listed above.




### 2 Assemble The Frame

Assemble the four 4pc Shock-Cord Poles by matching the labels to each other. Connect the ends of the four 4pc Shock-Cord Poles into the ends of the Top Poles creating two large arches.




### 3 Install The Poles

Connect the four Corners to the ends of the 4pc Shock-Cord Poles.



### 4 Install The Graphic

Using the six Hex Screws and the Hex Wrench, screw the three Support Poles and the Bottom Poles to one of the arches assembled in step 2. **Do not tighten at this time.** Support Poles have a slight arch to them. This arch needs to go towards the inside/underside of the frame.



### Storage & Care:

Store in a cool dry location. Clean hardware with a damp cloth. Machine wash the graphics in cold water on a gently cycle. Air dry only. Use a steamer for wrinkles. Never dry-clean.


# EZ-ZIP Round Trade Show Archway

## Assembly Instructions

1. 4pc Shock-Cord Poles (4)
2. Top Poles (x2)
3. Support Poles (x3)
4. Corner (x4)
5. Graphic
6. Hex Wrench
7. Hex Screws (x6)
8. Bottom Poles (x2)

### 5 Assemble The Frames

Assemble the two arches together as shown below. Tighten all Screws until snug but **do not over tighten.**




### 6 The Frame Looks

Your frame should now look like this



### 7 Install The Graphic

Lay the frame on its side and drape the printed graphics over frame and fasten the zipper around the frame. Carefully stand the Arch upright.



### 4 Stand Display Up



### Storage & Care:

Store in a cool dry location. Clean hardware with a damp cloth. Machine wash the graphics in cold water on a gently cycle. Air dry only. Use a steamer for wrinkles. Never dry-clean.